

NINJA AIR FRYER AF100 (4 QUART) **ACCESSORIES**



PRODUCT #	DESCRIPTION	FITS IN
PRD-73	Round cake pan solid bottom, 7"x3"	1
PRD-63	Round cake pan solid bottom, 6"x3"	1
PRD-53	Round cake pan solid bottom, 5"x3"	1
PRD-43	Round cake pan solid bottom, 4"x3"	1
PRD-33	Round cake pan solid bottom, 3"x3"	3
PSQ-553	Square cake pan solid bottom, 5"x5"x3"	1
PSQ-443	Square cake pan solid bottom, 4"x4"x3"	1
PSQ-333	Square cake pan solid bottom, 3"x3"x3"	1
PSF-63	Round springform pan, 18 gauge, 6" x 3"	1
PCC-73	Round cheesecake pan removable bottom, 7"x3"	1
PCC-63	Round cheesecake pan removable bottom, 6"x3"	1
PCC-53	Round cheesecake pan removable bottom, 5"x3"	1
PCC-43	Round cheesecake pan removable bottom, 4"x3"	1
PCC-33	Round cheesecake pan removable bottom, 3"x3"	3
RMP-7	Ring mold pan, 7.125" diameter top x 2.375" deep	1
RMP-5	Ring mold pan, 5" diameter top 2.25" deep	1
PIE-6	Pie pan, 6" OD x 4" ID 5" deep .5" rim	1
PIE-4	Pie pan, 4" OD x 4" 3" deep .5" rim	2
PFT-62	Fluted tart pan, 6" x 2", removable bottom	1
PFT-65	Fluted tart pan, 6.5" x 1", removable bottom	1
PFT-425	Fluted tart pan, 4.25" x 1", removable bottom	1
PFT-375	Fluted tart pan, 3.75" x 1", removable bottom	2

NINJA AIR FRYER AF100 (4 QUART) **ACCESSORIES**



PRODUCT #	DESCRIPTION	FITS IN
BP-5641	Bread pans oblong, 6.375" x 3.75" x 2	1
BP-5640	Bread pans oblong, 5.5" x 3.375" x 2	1
BP-5639	Bread pans oblong, 4.875" x 2.75" x 2"	2
PHA-625	Hemisphere pans, 6.25" diameter top x 3.125" deep	1
PHA-5	Hemisphere pans, 5.5" diameter top x 3" deep	1
PHA-4	Hemisphere pans, 4.5" diameter top x 2.5" deep	1
PHT-63	Heart cake pan solid bottom, 6"x3"	1



**ANODIZED ALUMINUM**  
Using Safe-Seal Technology



**BUILT BAKERY TOUGH**



**CREATE. BAKE. DECORATE. SHARE.**